

WARNING! Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire.

Notice for users in California - CR Coin Cell Lithium Battery information: This product contains a CR Coin Cell Lithium Battery which contains Perchlorate Material – special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.



Document Number: 57100-1 57A00-1
Installation Instructions

The 57A00-1 Vanishing Door/Window Transmitter is a supervised wireless contact that works with the HAI 45A00-1 Wireless Receiver. It has beveled edges that vanishes into any décor. It also features a bypass button that allows you to manually bypass the transmitter, which automatically restores when the magnet is replaced.



Federal Communications Commission (FCC) Statement:

This equipment has been tested to FCC requirements and has been found acceptable for use. The FCC requires the following statement for your information:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interferences to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- If using an indoor antenna, have a quality outdoor antenna installed.
 - Reorient the receiving antenna until interference is reduced or eliminated
 - Move the receiver away from the control/communicator.
 - Move the antenna leads away from any wire runs to the control/communicator.
 - Plug the controller into a different outlet so that it and the receiver are on different branch circuits.
- If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions.

The user or installer may find the following booklets prepared by the Federal Communications Commission helpful: "Interference Handbook". This booklet is available from the U.S. Government Printing Office, Washington, DC 20402. The user shall not make any changes or modifications to the equipment unless authorized by the installation instructions or User's Manual. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To remove cover, insert screwdriver here, and gently twist




Figure A

Once cover is removed, insert the battery with the positive (+) side up as indicated in Figure B.




Figure B

Locate Transmitter

Select the location where the 57A00-1 is to be mounted.

NOTE: RF signals can be affected by metal objects, including metal doors or large mirrors. Such locations should be avoided as they can interfere with proper operation.

Mounting the 57A00-1

Once you have determined the proper location, the 57A00-1 can be permanently mounted using the supplied adhesive tape.

NOTE: It is the responsibility of the installer to ensure that the 57A00-1 is securely mounted in the intended location.

Using Adhesive Tape:

Ensure that the surface is clean and dry. Apply the supplied tape to the back of the 57A00-1, press and hold firmly in the desired location for

approximately 10-15 seconds. It can take up to 24 hours for the tape to reach maximum bonding strength.

Mounting the Magnet

Align the magnet with the 3 notches on the 57A00-1 housing. Mount the magnet a maximum of .4" from the 57A00-1 by using the supplied tape.

Enrolling the 57A00-1

To enroll the 57A00-1, put the 45A00-1 Wireless Receiver into Setup mode and advance to an unused address location. Activate the reed switch by removing the magnet from the transmitter for 1 second, then replacing it. Refer to the Installation Instructions for the 45A00-1 for additional information.

Using the Bypass Button:

To temporarily bypass the transmitter so that you can open an armed door or window without causing an alarm, press the center of the transmitter and hold for 5 seconds. Once you remove your finger, you will notice that the LED behind the transmitter's front panel will begin to blink.

While the LED is blinking, the transmitter will not transmit any signals to the receiver (you may open the door or window while the LED is blinking without causing an alarm). Once the LED stops blinking, the next time the magnet is removed from the transmitter (i.e. the door or window is opened), the signal will be transmitted to the receiver.

Notes:

1. When activated, the LED will blink for approximately 7 seconds.
2. If the door or window is open when the LED stops blinking, once the door or window is closed, the transmitter is restored. The next time the door or window is opened, the signal is transmitted.

Tamper Switch

Out of the box the 57A00-1 comes equipped with cover tamper detection. If the cover is removed, the 57A00-1 will report a zone tamper (cover off) to the receiver.